

# Technische Fiche SPARK (updated 05 mei 2006)

PRAKTIKABEL 2 x 2 M  
220V  
**KEYBOARDS**  
MON 5

PRAKTIKABEL 2 x 2 M  
220 V  
**DRUMS**  
MON 6

220 V  
**BAS**  
MON 7 MON 8

220 V

220 V

Gitaar + backing

LEAD

Gitaar

MON 1 DI acc guit

MON 2

MON 3

MON 4 DI acc.guit.

STAGE				FOH				MONITOR				
1	KICK	SM91		□	1	KICK	TLA 1	1	LEX A	KICK	1	DRUM
2	SNARE	SM57	SB		2	SNARE	JBL COMP	2	LEX B	SNARE	2	DRUM MIX
3	HIHAT	AKG451	SB	□	3	HIHAT		3	TC 2000	HIHAT	3	BASS
4	TOM 1	MD504			4	TOM 1	GATE 1	4	TC 2290	TOM 1	4	GITAAR
5	TOM 2	MD504			5	TOM 2	GATE 2	5		TOM 2	5	KEYBOARD
6	TOM 3	MD504			6	TOM 3	GATE 3	6		TOM 3	6	GUNTER
7	FLOOR	MD504			7	FLOOR	GATE 4	7		FLOOR	7	CLAUDIA
8	OVERH R	AKG414	SB	□	8	OVERH R		8		OVERH R	8	FX SEND 1
9	OVERH L	AKG414	SB	□	9	OVERH L		9		OVERH L	9	FX SEND 2
10	BASS	DI		□	10	BASS		10		BASS	10	
11	E GIT (stereo)	SM57x2	SB		11	E GIT Lange Pol		11		E GIT Lange Pol	11	
12	ACC GIT GUNTER	DI		□	12	ACC GIT GUNTER		12		ACC GIT GUNTER	12	
13	E GIT GUNTER	SM 57	SB		13	E GIT GUNTER		13		E GIT GUNTER	13	
14	PIANO L	DI		□	14	PIANO L		14		PIANO L	14	
15	PIANO R	DI		□	15	PIANO R		15		PIANO R	15	
16	KEY BOARD L	DI		□	16	KEY BOARD L		16	SUB	KEY BOARD L	16	
17	KEY BOARD R	DI		□	17	KEYBOARD R				KEY BOARD R	17	
18	VOC GUNTER	SM 58	SB		18	VOC GUNTER	TLA 2			VOC GUNTER	18	
19	VOC CLAUDIA	SM 58	LB		19	VOC CLAUDIA	TLA 3			VOC CLAUDIA	19	
20					20	A LEX L					20	
21					21	A LEX R					21	
22					22	B LEX L					22	
23					23	B LEX R					23	
24					24	TC 2000 L					24	
25					25	TC 2000 R					25	
26					26	TC 2290 L					26	
27					27	TC 2290 R					27	
28					28	CD / DAT L					28	
29					29	CD / DAT R					29	
30					30						30	
31					31						31	
32	SPARE				32	SPARE				SPARE	32	